



BHMFit contact*forte*

Instruction for Use



Contents

1. Introduction	3
1.1. <i>Intended use</i>	3
2. System requirements	3
3. Installation	4
4. Connecting hearing aid with programming interface	4
5. User interface	5
5.1. <i>Sections</i>	5
5.2. <i>Menu bar</i>	5
5.3. <i>Navigation menu / Navigation button</i>	6
5.4. <i>Working section</i>	6
5.5. <i>Actions bar</i>	7
5.6. <i>Status bar</i>	7
5.7. <i>Features bar</i>	7
6. Fitting procedure	8
6.1. <i>Customer management</i>	8
6.1.1. Search customer	8
6.1.2. Create new customer	9
6.1.3. Customer data	9
6.2. <i>Devices</i>	12
6.3. <i>Fitting</i>	13
6.3.1. Gain	15
6.3.2. Filter	16
6.3.3. Equalizer	17
6.3.4. Hearing comfort	18
6.4. <i>Options</i>	19
6.5. <i>Finalization</i>	21
7. Key 23	

Intended use: The software enables the fitting of compatible bone conduction hearing aids.

User group: The software is designed and intended for use by a specialist (audiologist, acoustician, ENT doctor).

Contraindications: Adjustment of hearing aids from other medical device manufacturers.

These instructions apply to the BHMFit contact forte with version 1.0.0.1.

1. Introduction

1.1. Intended use

The fitting Software **BHMFit contact forte** is a tool intended to adjust the programmable hearing aids **contact forte** from BHM-Tech according to the needs of people with hearing loss. The fitting must be performed by a hearing health specialist, e.g. audiologists, acousticians or ENT doctors.

Read and follow the instructions of this user guide to avoid injuries to the patient or damage to the hearing aids.



The **BHMFit contact forte** is designed for a lifetime of 5 years from the time of installation. Only the latest version of the software may be used. Please check whether a newer version is available before using the software.



All serious incidents that occur in connection with the product must be reported to the manufacturer of the device and the competent authority.



Limitation of use: Reference is made to the fact that modifications to hearing aids may only be carried out by hearing aid acousticians or authorised specialists. The correct functioning of the hearing aid depends crucially on correct fitting. Adaptations must be carried out with extreme caution so follow the instructions for use for the hearing aids and note the output level of the hearing aids.

2. System requirements

BHMFit contact forte is using a database that allows the efficient management of customer information:

- Customer contact information
- Session list
- Audiogram data

BHMFit contact forte can be used on systems that meet the following requirements:

Supported operating systems:

- Windows 7, 8.1, 10 - 32 & 64 Bit; Windows 11; Windows Server 2008, 2010 - 32 & 64 Bit

Minimum requirements:

- PC with DVD drive or USB port
- Free hard disk space: 100 MB (Fitting Software) and 150 MB (Database)
- 4 GB RAM
- Screen resolution: 1024 x 768
- Programming interface: NOAHlink, HI-PRO
- Programming cable
- Microsoft .NET Framework 4.5
- Adobe Acrobat Reader
- Microsoft Word (Export of the fitting protocol)

NOAHlink™ and HIMSA are trademarks or registered trademarks of the Hearing Instrument Manufacturers Software Association (HIMSA A/S). USB® is a trademark or registered trademark of USB® Implementers Forum, Inc. Windows® XP, Windows® Vista, Windows® 7, Windows® 8 and Windows® 10 are trademarks or registered trademarks of the Microsoft® Corporation.

PDF™ and Adobe® are trademarks or registered trademarks of Adobe® Systems Incorporated. Any other brands or product names mentioned are trademarks or registered trademarks of their respective owners.

3. Installation

Note: Administrator privileges are required to avoid installation problems.



- Close all running Windows applications before starting the installation. Other running programs or virus scanner could affect or block the installation.
- Open the **BHMFit contact forte** setup application to start the installation, if it does not start automatically.
- Follow the instructions on the screen.

4. Connecting hearing aid with programming interface


NOAHlink, and HI-PRO is supported as a programming interface. The programming interface must be installed on your computer. For the installation, please use the documents and software from the manufacturer of the programming interface.



The programming socket on the **contact forte** is located at the bottom of the hearing aid and is protected by a socket cover and a socket seal that must be removed before the programming cable is connected.

The socket cover and the socket seal provide protection from dust and moisture and must be reinstalled after fitting of the hearing aid. Please refer to the device instruction for use for details.

Gently connect the programming cable to the programming interface with the Mini-DIN connector and to the hearing aid with the 4-pin hearing aid connector. Please make sure that the red marking on the programming cable connector is on the same side as the yellow marking on the programming socket. Otherwise, you will have no connection i.e. may destroy the programming socket! The hearing aid must always be turned off when connecting and unplugging the programming cable.



Please remove the battery during the programming process.

Programming cable (not supplied with the contact forte):

Use a cable with the standard wiring as per HIMSA specification, or a compatible cable.

Examples of compatible programming cables:

- Beltone: 902290769029
- BHM article number: 77733408 (VBK No. 99/150-RED right)
- Siemens: Connex 3
- BHM article number: 77733409 (VBK No. 99/150-BLUE left)
- Oticon: No. 3



The **contact forte** may only be programmed with the programming interfaces and programming cables mentioned above. If unauthorized programming interfaces and programming cables are used, there is a risk of injury to patients and damage to the hearing aid.



When programming the **contact forte**, the battery must be removed from the hearing aid. If a battery is inserted during the programming process, it may possibly charge the hearing aid battery and cause the hearing aid to overheat. Skin burns can be the result.

5. User interface

5.1. Sections



The screenshot displays the BHMFit contact forte software interface. At the top, there is a title bar with 'BHMFit contact forte | en | New session' and a menu bar with 'File', 'Settings', 'Data Logging', and 'Help'. Below the menu bar is a navigation menu with tabs for 'Devices', 'Fitting', 'Options', and 'Finalization'. The main working section is titled 'Working section' and shows two frequency response graphs for 'P1: Comfort' and 'P2: Comfort'. The graphs plot Output [dB(DFL)] on the y-axis (0 to 130) against Frequency [Hz] on the x-axis (125 to 12k). Below the graphs are two tables of data for G50 and G80 frequencies, and a table for CR and MPO values. The interface also includes an Actions bar on the left with options like Gain, Filter, Equalizer, and Hearing comfort. A Status bar at the bottom shows 'contact forte' and 'Hi-Pro Simulation'.

5.2. Menu bar

File Settings Data Logging Help

File

- *Import data* information from BHMFit contact mini, contact star ev01, BHMFit2 or NOAH (NOAH XML File)
- *Export data* information to NOAH (CSV File)
- *Close the program*

Settings

- *Acoustician data* can be entered and saved. Data will be shown on the fitting report and on the customer's info page.

Acoustician x

Company Company logo

First name Last name

Address

Street Nr City

ZIP Country

Contact

E-Mail


Phone Mobile

- *Programming device* setting. Select between HI-PRO or NOAHlink.
- *Factory settings*. The hearing aid is restored to the factory settings.

- *Language.* Select the language of the software.

Data logging

- *Show logged data of the device usage.*



To show out the logged data, the “data logging” option must be enabled. See chapter 6.4. “Options”.

Help

- *Instruction for Use*
- *About...*

5.3. Navigation menu / Navigation button

The navigation menu guides the user step-by-step through the fitting session. The individual menu items can be selected directly or accessed with the "Navigation button" (bottom right) during a systematic fitting procedure.



The active menu is underlined and the completed menus are greyed-out. It is always possible to make a step back in the menu.

5.4. Working section

The main settings and entries for the fitting session can be made in the working section. Different setting options depending on the navigation menu items are possible.



The various setting and selection options related to the respective navigation menu item are described in the chapter “Fitting procedure”.

5.5. Actions bar

In the actions bar, various options are offered as part of the fitting session in the various navigation menu items.



The various action options related to the respective navigation menu item are described in the chapter "Fitting procedure".

5.6. Status bar



The status bar displays the following:

- Connection status of the hearing aid on the right side
- Connected / selected hearing aid on the right side
- Connection status of the programming interface
- Connection / selected programming interface
- Connected / selected hearing aid on the left side
- Connection status of the hearing aid on the left side

The following status information is displayed:



The hearing aid / the programming interface is not connected.



The hearing aid / the programming interface is connected.



The green status indicates that the settings configured in the software have been transferred to the hearing aids but have not yet been permanently programmed. Permanently programming in the hearing aids is performed at "Finalization" executing "Program and save". See chapter 6.5.

5.7. Features bar

In the features bar, various features are offered as part of the fitting session in the various navigation menu items.



The various action options related to the respective navigation menu item are described in the chapter "Fitting procedure".

6. Fitting procedure

6.1. Customer management

Customer management appears at the start of every hearing aid fitting. This is where the following customer data can be managed:

- Personal data
- Audiogram data
- Sessions list

Actions bar



6.1.1. Search customer

With the following action buttons, customers from the list can be selected or deleted.



An additional customer search option is also available.


 A screenshot of a search interface. At the top, there is a search bar with the text "Search customer". Below it is a large empty text area. At the bottom, there is a search input field with the placeholder text "Search e.g. Mustermann" and a "Go!" button. Below the search field is a table header with the following columns:

Nr.	Last name	First name	Date of birth	Customer number	Sex	Actions
-----	-----------	------------	---------------	-----------------	-----	---------

6.1.2. Create new customer

New customer can be created.

When you create a new customer, the “Create new customer” data view will appear. Here, the customer data can be entered.

Create new customer

Personal information

Name *

Date of birth

Sex ♂ ♀

Contact information

Address

Country

Comment

Profile

Customer number

Insurance

Insurance number

Phone

Phone

Mobile

Email



Save the entered customer by clicking the “Save” button at the features bar. The customer will be added to the customer database.



To create and save a customer, you need to enter at least the first name and the last name .

6.1.3. Customer data

Once a customer was created or selected, the customer data can be edit in the “Customer data” view .

Customer data

Personal information

Name *

Date of birth

Sex ♂ ♀

Contact information

Address

Country

Phone

Mobile

Email

Creator

Last modified by

Profile

Consecutive number


Customer number

Insurance


Insurance number

Audiogram

R



L



Add a comment



Add a comment to the customer by clicking the “Comment” button at the features bar. Once you have entered a comment, a red dot will appear at the comment button.

Entering an audiogram




Enter or edit the customer audiogram by clicking the “Audiogram” button at the features bar or by double-clicking the audiogram display at the customer data view.

The following threshold values can be entered:

- BC – Bone conduction threshold
- AC – Air conduction threshold
- MCL – Most comfortable level
- UCL – Uncomfortable level

Selecting BC, AC, MCL or UCL enables data to be entered into the audiogram. Set data points with left-click or return key at the desired frequency and hearing loss position. The data for the right ear (RED) is entered in the graph on the left and the data for the left ear (BLUE) in the graph on the right.

Delete data points again by right-click or backspace key.



Additional features:

- *Copy audiogram to the left/right* – copies the audiogram from one side to the other
- *Delete selected curve* – deletes the audiogram data points from the selected curve
- *Delete all curves* – deletes the audiogram data points from all curves entered from one side




Save the entered audiogram data by clicking the “Save” button.



A hearing loss must not be entered for every frequency. For First-Fit calculation (see chapter 6.3.) the BC threshold data for the frequencies 500 Hz, 1 kHz, 2 kHz and 4 kHz must be set.

Open session list


 Open the session list by clicking the “Sessions” button at the features bar .




In the session list a new session can be created, or a previous saved session can be loaded or deleted. The session list can also be closed with the button “Cancel”.



If no saved session is selected, a new session is automatically created whenever the next navigation menu point is clicked. A session can only be saved at the end of the fitting procedure executing “Program and save”. See chapter 6.5.


Navigate to “Devices”


 Go to the next navigation menu point by clicking the “Devices” navigation button. This can also be done by clicking the “Devices” item at the navigation menu.

6.2. Devices

The hearing aids used for the fitting must be selected. This can be done automatically by detecting connected hearing aids (the hearing aids must be connected to the programming interface with a suitable programming cable – see chapter 4.) or manually by executing the simulation mode.

The detected hearing aids will be displayed with the serial numbers for the respective side (right/left). In simulation mode the word “Simulation” is shown instead of the serial number.



Actions bar



Detect:

A detection of the devices, after the simulation mode has been selected, is possible.

Additional features:

Transfer device from one side to the other side (only in simulation mode)

Data sheet of the selected device

Instruction for Use of the selected device

First-Fit



Execute a fast fitting by clicking the “First-Fit” button at the features bar. Certain values must be entered at the audiogram to run First-Fit. For more information see chapter 6.3.

Navigate to “Fitting”




Go to the next navigation menu point by clicking the “Fitting” navigation button. This can also be done by clicking the “Fitting” item at the navigation menu.

6.3. Fitting

The following settings can be configured for the hearing aids individual programs in the "Fitting" section:

- Program modes with the corresponding input modes (Front-End Modi)
- Gain (G50, G80, MPO)
- Volume Control
- Filter (Low-cut, High-cut, Notch)
- Equalizer
- Hearing Comfort (Feedback Cancellation, Noise Reduction)
- Read device data
- Copy device settings
- Transfer program settings
- Fitting-Assistant
- First-Fit



The screenshot displays the BHM fitting software interface. It features two audiogram graphs showing Output [dB/PL] vs. Frequency [Hz] for G50 and G80 programs. Below the graphs are frequency sliders for VC (Volume Control) and a data table for various parameters.

	All	250	500	750	1k	1,5k	3k	6k	10k
G50	24	24	24	24	24	24	24	24	24
G80	24	24	24	24	24	24	24	24	24
CR	1:1	1:1	1:1	1:1	1:1	1:1	1:1	1:1	1:1
MPO	86	101	114	116	109	101	102	97	

Mute/Unmute



The signal output of the hearing aids can be switched off (mute) or switched on (unmute) during the fitting session by clicking the Mute/Unmute button.

Couple/Decouple

Only possible at binaural fitting of hearing aids.



Hearing aids are decoupled. Changes at one hearing aid at one side will not affect the hearing aid on the other side.



Hearing aids are coupled. Changes at one hearing aid at one side will also affect the hearing aid on the other side.

Program selection

Up to 4 programs can be configured – P1, P2, P3 and P4. A click at the arrow on a given program opens a drop-down menu from which the desired pre-defined hearing program modes can be selected.



The following pre-defined hearing program modes are available. Each program mode is pre-defined with a Front-End mode.

Program mode	Front-End mode	Available for			
		P1	P2	P3	P4
Not active	-	No	Yes	Yes	Yes
Automatic*	Microphone	Yes	No	No	No
Music & movie	Microphone	Yes	Yes	Yes	Yes
Comfort	Adaptive directivity	Yes	Yes	Yes	Yes
Speech loud environment	Adaptive directivity	Yes	Yes	Yes	Yes
Speech quiet environment	Adaptive directivity	Yes	Yes	Yes	Yes
Phone acoustic	Microphone	Yes	Yes	Yes	Yes
BT	Bluetooth	No	Yes	Yes	Yes
BT + M (Omni)	Bluetooth + microphone	No	Yes	Yes	Yes



All program modes have to be fitted manually. Only the Front-End mode is pre-defined for every program mode.

*Automatic

In Automatic mode, the signal received by the microphones is analysed and categorised into different hearing situations. These are:


- Quiet environment
- Speech in quiet environment
- Loud environment
- Speech in loud environment
- Musical environment
- Windy environment

The parameters of the hearing aid are always configured according to this categorisation such that an optimal level of hearing comfort and optimal speech comprehension are attained.

Display

By clicking at the drop-down menu, between the two graphical displays, the view mode can be chosen.

- Output
- Gain
- Input/Output
- Input/Gain



VC (Volume control)




The "VC" slider allows to adjust the hearing aids output volume in 2 dB steps from -32 dB to 0 dB.

Actions bar




6.3.1. Gain

The gain and maximum power output (MPO) for the hearing aids can be set for eight frequency channels via a gain matrix. The values of the cells selected can be increased and decreased.



The gain matrix view can be simplified by clicking on the [] button.



G80 / G50 gain:

Select the gain values to be changed:

- Select individual gain values in the matrix by clicking on a cell or dragging the cursor over several cells.
- The "All" button selects all cells.
- The "G80" and "G50" buttons select the entire row.
- Clicking on the frequency selects the entire column.

It is possible to increase or decrease the gain values in 1, 3 or 5 dB steps by clicking the appropriate button next to the gain matrix.



The compression ratio is adjusted automatically according to the gain settings for the G80 and G50 values.

It may be the case that values cannot be increased or decreased when setting the gain via the gain matrix. Possible reasons for this:

- The minimum or maximum gain has been reached.
- The value for G50 cannot be less than G80.
- The value for G80 cannot be greater than G50.
- The compression inside the channel cannot exceed $\infty:1$.


MPO (Maximum Power Output):

The MPO (Maximum Power Output) limits the output force level of the hearing aids. Force levels exceeding the selected threshold are restricted. The maximum output signal level can be reduced in 1, 3 or 5 dB steps with the MPO by clicking the appropriate button next to the gain matrix. It is possible to adjust the MPO for every single frequency channel.

6.3.2. Filter

The following filter settings can be configured.

- High-cut filter
- Low-cut filter
- Notch filter




High-cut filter:

The high-cut filters high frequencies above a selectable frequency. It is disabled when the slider is on the right. Otherwise, it is possible to select a limiting frequency between 8000 Hz and 1000 Hz. This function has proven very effective in practice at suppressing unwanted, high frequency signal parts and disturbing noises.

Low-cut filter:


The low-cut filters low frequencies below a selectable frequency. It is disabled if the slider is on the left. Otherwise, it is possible to select a limiting frequency between 125 Hz and 2000 Hz. This filter reduces the maximum output level at low frequencies. In most cases, this results in considerably clearer sound reproduction and improved speech intelligibility. The power consumption of the hearing aid is also reduced.

Notch filter:

The notch filter filters out frequencies within a narrow frequency range. The notch filter can be used to attenuate unwanted feedback and interfering frequencies by reducing the signal level of the relevant frequency. By clicking the  button the notch filter can be activated or deactivated. The amount by which the gain can be adapted is between +10 and -30 dB in 2 dB steps. The relevant notch filter's centre frequency can be selected between 1000 Hz and 11500 Hz. The width of the notch filter can be defined according to the quality factor between 0.5 and 100.

6.3.3. Equalizer

The hearing aids have a 16-band equalizer. The equalizer allows high-precision correction of hearing loss. Each of the equalizer sliders alters the gain in the corresponding frequency band. The level for the selected frequency can be lowered or raised using the appropriate slider.





There are separate equalizers for left and right. By clicking at the appropriate tab the equalizer function for the right side (red) or left side (blue) will be chosen.

The default value for the equalizer frequency bands is 0 dB. It is possible to change the gain in the range -18 dB to +6 dB for every frequency band.

Each frequency band can be changed separately with the appropriate slider.

Additional it is possible to combine single frequency bands by clicking at the dB-values at the bottom of the frequency bands. Combined frequency bands would be marked with a tick.


By clicking the  button all frequency bands will be combined.

By clicking the  button all frequency bands will be reset to default values.

6.3.4. Hearing comfort

The hearing comfort section provides the following options for reducing feedback and background noise:

- Adaptive feedback cancellation
- Adaptive noise reduction



Adaptive Feedback Cancellation:

The hearing aids have adaptive acoustic feedback management. Acoustic feedback, whistling, etc. are automatically minimised once the suppression of feedback is enabled. The gain of the hearing aids remains unaffected and is not reduced.

Adaptive Noise Reduction:

The hearing aids are able to reduce irritating noises and artefacts by means of noise reduction. It is particularly effective when the customer is dependent on good speech understanding in an acoustic environment with a wide range of background noise.

The following levels can be selected:

- Off – no noise reduction
- Low – noise reduction of 3 dB
- Moderate – noise reduction of 6 dB
- High - noise reduction of 9 dB

Read device data



Reading out the settings from the hearing aids by clicking the "Read device data" button at the features bar.

Copy device settings



Copying the current settings from one hearing aid to the other hearing aid by clicking the "Copy device settings" button at the features bar. This function is only possible for binaural fitting.

Transfer settings



Transferring the current settings from one program to another program by clicking the "Transfer settings" button at the features bar. For binaural fitting it can be decided to transfer the settings only in one hearing aid (left or right) or in both hearing aids.

Fitting-Assistant



Opening the Fitting-Assistant by clicking the "Fitting-Assistant" button at the features bar. The Fitting-Assistant helps to fine-tune the hearing aids to customer requirements in realistic situations. Here you will find examples from everyday situations, such as "Traffic noise too loud", and with suggestions for personal optimisation.

Procedure:

- Selecting the desired category:
 - Comfort
 - Sound quality
 - Speech intelligibility
- Selecting the respective situation, like “Voices too loud”, ...
- Selecting one of the suggested possible solution.
- Executing the suggested solution for the left, for the right or for both hearing aids.

Every action can be undone by clicking the “Undo” button.



Once the desired selection is executed, a message “Changes applied” will appear next to the execute buttons. All executions will be carried out immediately.

First-Fit



Selecting and executing a fitting algorithm by clicking the "First-Fit" button at the features bar. It can be selected between the following fitting algorithms.

- BHM-BC-Fit
- BHM-BC-NL (unilateral or bilateral consideration)

The fitting targets of the algorithms will be shown as dashed lines in the display of the output and gain graph in the main window.



To execute a First-Fit algorithm, at least the 500 Hz, 1000 Hz, 2000 Hz and 4000 Hz bone conduction (BC) audiogram values have to be entered at the audiogram. The more data points are set, the more accurate the First-Fit calculation will be. All other threshold data are optional and have no influence on the First-Fit calculation.

Navigate to “Options”




Go to the next navigation menu point by clicking the “Options” navigation button. This can also be done by clicking the “Options” item at the navigation menu.

6.4. Options

The following settings are available in the options section:

- Signal sounds activation/deactivation
- Volume of signal sounds
- Data logging activation/deactivation
- Startup delay
- Key lock activation/deactivation
- Wireless connection activation/deactivation




Mute/Unmute



The signal output of hearing aid can be switched off (mute) or switched on (unmute) during the fitting session by clicking the Mute/Unmute button.

Couple/Decouple

Only possible at binaural fitting of hearing aids.



Hearing aids are decoupled. Changes at one hearing aid at one side will not affect the hearing aid on the other side.



Hearing aids are coupled. Changes at one hearing aid at one side will also affect the hearing aid on the other side.

Signal sounds

The signal sounds section allows the individual volume setting or deactivation of the following:

- Program selection
- Battery sound
- Startup sound
- Wireless pairing
- Volume control
- Wireless connection off



The “On/Off” button allows signal sounds to be activated or deactivated.



The “Volume” slider allows to adjust the signal sounds volume in 6 dB steps [-12 dB, -6 dB, 0 dB, +6 dB, +12 dB].



The “play” button allows signal sounds to be played directly on the connected hearing aid.

Data logging



Activate data logging can be switched on or off. If data logging is activated, the customer's usage behaviour and program use will be recorded. This data can be read out and displayed under "Data Logging" in the menu bar.

General

- Startup delay



The startup delay defines the number of seconds to delay between when initialization completes and application processing begins. The startup signal sounds after the specified startup time.

- Key lock



Activate or deactivate the control buttons of the hearing aid.

- Wireless connection



Activate or deactivate the Bluetooth connectivity functions.



Navigate to "Finalization"



Go to the next navigation menu point by clicking the "Finalization" navigation button. This can also be done by clicking the "Finalization" item at the navigation menu.

6.5. Finalization

Before the adjusted settings are programmed to the hearing aids and the session is saved, the main settings are once again displayed in an overview.

contact forte S/N: Simulation		R	Finalization	L	S/N: Simulation contact forte	
Name	contact forte		Name	contact forte		
S/N:			S/N:			
Fitting formula	-		Fitting formula	-		
Hearing programs	Automatic Music & movie Speech loud environment Speech quiet environment		Hearing programs	Automatic Music & movie Speech loud environment Speech quiet environment		
Signal sounds	Battery sound Startup sound Wireless pairing Program selection Volume control Wireless connection off		Signal sounds	Battery sound Startup sound Wireless pairing Program selection Volume control Wireless connection off		
Data logging	Activated		Data logging	Activated		
Startup delay	3 Seconds		Startup delay	3 Seconds		
Wireless connection	Activated		Wireless connection	Activated		
Key lock	Deactivated		Key lock	Deactivated		

The following functions are available at this point:

- *Session notes*
- *Print information sheet*
- *Print report*

Session notes



Add some comments to the actual session by clicking the “Session notes” button at the features bar. Once you have entered a comment, a red dot will appear at the comment button. The entered text will appear in the print information sheet and in the print report.

Print information sheet



Print an information sheet by clicking the “Print information sheet” button at the features bar. This sheet contains information about the hearing aids used and a few points that will be useful to the customer (such as hearing program assignment). The information sheet can be print to file (.pdf format) or can be print directly.

Print report



Print a fitting report by clicking the “Print report” button at the features bar. The fitting report contains both customer data and all the settings configured on the hearing aids fitted during the session. The fitting report can be print to file (.pdf format) or can be print directly. A session name can be defined and will appear in the fitting report. The defined session name will be automatically assumed to the “Program and save” window.

Program and save



Programs the fitting data and settings to the hearing aids and saves the customer session. Clicking on the “Program and save” button offers the following save options: save the session to the customers data base (a session name can be defined optional), save the settings to the connected hearing aids, or both.

After selecting the save options it is possible to save and exit the fitting software or to save and start a new session.

7. Key

Symbols



Warning! Pay attention to the warnings notices in these instruction for use



Important information for usage and product safety



CE marking and Notified Body number



UDI – Unique Device Identification



Manufacturer



Date of manufacture



Consult instruction for use



BHM-Tech Produktionsgesellschaft mbH
Grafenschachen 242
7423 Grafenschachen
Austria
www.bhm-tech.at

support@bhm-tech.at

